



JP-1 JUMPERS & CONNECTIONS

To Use On-board Sensor(s)

- Light Sensor: Jumper AIN 2 to INPUT 2
- Temperature: Jumper AIN 1 to INPUT 1
- Potentiometer: Jumper AIN 0 to INPUT 0

To Input External Analog Input Signals:
Remove the Jumper and Connect
Signal to The Appropriate **AIN** Pin

Analog (DAC) Output:
Connect to **AOUT** Pin

Information including Drawings, Schematics, Links and Code (Software) Supplied or Referenced in this Document is supplied by MPJA inc. as a service to our customers and accuracy or usefulness is not guaranteed nor is it an Endorsement of any particular part, supplier or manufacturer. Use of information and suitability for any application is at users own discretion and user assumes all risk.

All rights are retained by the respective Owners/Author(s)
Information is Subject to Change Without Notice

www.mpja.com

Title **4 Channel DAC/ADC Module**

Size Document Number **36806 MP** Rev.

Date Sheet